







- a.** If there's a stud behind the wall, drive a #10 screw (not included) through the wall and into the stud.
 - b.** If no stud, install a #10 wall anchor (not supplied).
Following the wall-anchor manufacturer's instructions.
 - c.** For masonry walls, use a masonry drill bit and #10 masonry anchor and screw (not included).
- 2.** Tighten screws into stud or wall anchors, leaving screw heads protruding 1/4" (6mm).
 - 3.** Make all wire attachments now.
 - 4.** Line up the keyhole slots so the screw heads pass through the large center hole of the slots.
 - 5.** Let the speaker slide straight down, allowing the screw head to slip behind the smaller end of the keyhole slot.
 - 6.** Tug gently on the speaker to make certain the screws and bracket are properly aligned and that the wall anchors are secure.
 - 7.** If the bracket is not held snug against the wall, remove the speaker from the wall, drive the screws in a little further, then remount the speaker.

- a.** S'il y a un montant derrière la surface du mur, vissez des vis #10 (non fournies) à travers le mur et dans le montant.
 - b.** S'il n'y a pas de montant, installez des chevilles d'ancrage #10 (non fournies) selon les instructions du fabricant.
 - c.** Pour les murs en maçonnerie, utilisez un foret à maçonnerie puis des chevilles d'ancrage et des vis #10 (non fournies).
- 2.** Vissez les vis dans le montant ou les chevilles, laissant les têtes de vis dépasser de 6 mm (1/4").
- 3.** Connectez maintenant le fil de h.p.
- 4.** Alignez l'enceinte de façon à ce que les têtes de vis pénétrant la partie évasée des fentes en trou de serrure.
- 5.** Laissez glisser l'enceinte vers le bas, permettant aux têtes de vis de pénétrer la partie étroite des fentes en trou de serrure.
- 6.** Tirez doucement l'enceinte pour vous assurer que les vis et le support sont bien alignés et que les chevilles sont bien ancrées.
- 7.** Si l'enceinte n'est pas retenue solidement au mur par les têtes de vis, retirez l'enceinte, vissez les vis un peu plus profondément puis remplacez-la.



The Dynamic Sonic Engine should point toward the listening area for both side wall and back wall mounting.



Side walls:


- Left and right F/X surrounds mount on left and right side walls, respectively.

Side walls:




- Left and right F/X surrounds mount on left and right side walls, respectively.

Rear walls:

- The right F/X Surround speaker becomes the left Surround Rear.
- The left F/X Surround speaker becomes the right Surround Rear.



Les transducteurs Dynamic Sonic Engine doivent être orientés vers la zone d'écoute - que l'enceinte soit installée sur un mur latéral ou le mur arrière.



Murs latéraux:

- Les enceintes F/X gauche et droite s'installent respectivement sur les murs latéraux gauche et droit.

Murs latéraux:

- Les enceintes F/X gauche et droite s'installent respectivement sur les murs latéraux gauche et droit.

Mur arrière:

- L'enceinte F/X droite devient l'ambiophonique gauche arrière.
- L'enceinte F/X gauche devient l'ambiophonique droite arrière.

HBP2363B

LSiM702F/X Wall Mount Template
(20" W x 17" H) Full Size

Date	22 November 2010	Approvals	Signature	Date
Drawing #	HBP22363	Project Manager		
File Name	LSIM702FX_WallTemp2363B.eps	Product Line Manager		
Scale	Full Size	Mechanical Designer		
Drawn By	KLB	System Engineer		
Color	Prints 100% black	Electrical Engineer		
Emboss Ht.	n/a	Safety & Regulations		
Deboss Depth	n/a	Quality Assurance		
Finish	n/a	Creative Director		
Process	Offset Lithography	Comments		
Notes	Stock: 100 lb text weight (148 gsm), White matte finish Die-lines DO NOT PRINT. Layout size: 17" x 20"; Folds in quarters: Fold Size: 8.5" x 10"			
Artwork	Digital file			

[illegible]